



OPERATING INSTRUCTIONS

1. Set Sample Valve to **SAFE**.
2. Remove Flex Line from fixed quick connect.
3. Connect Sample Cylinder to Gas Sampler.
4. Open Valves on Sample Cylinder.
5. Turn Gas Sampler Valve to **SAMPLE**.
6. Purge for 10 sec.
7. Close top Sample Cylinder valve first, wait 10 sec. & close bottom Sample Cylinder valve.
8. Set Sample Valve to **SAFE**.
9. Remove Sample Cylinder.
10. Replace Flex Line in fixed quick connect.



Drawing # 100305	Scale 25%	Date 4/11/01
Rev # R0	Drawn by MA	Rev by
Title Vapor 3-Way, 500 cc SS Cylinder, 60 PSI Gauge, 135BM		Date
SAMPLING SYSTEMS		708 N Main St, Sweeny, TX 77480
		979-647-1070, Fax 979-647-1072
		www.sampling-systems.com